



MANUAL UPDATE

NEW MESH SCREENS

We have changed the herb chamber mesh screen of the Iolite Vaporiser, please find instructions below: -

1. Remove the herb chamber from the iolite
2. Unscrew the mouthpiece from the herb chamber
3. Using the narrow end of the hand tool, push the old mesh out
4. Again using the larger end of the hand tool, push the new mesh into position with the holes facing the back of the herb chamber
5. Using the hand tool push the retention ring into the herb chamber to secure the mesh.

*If you have any difficulties
or further enquiries please contact us.*

iolite[®] Oglesby and Butler Ltd., O'Brien Road, Carlow, Ireland.

Tel: +353 59 914333 | **Fax:** +353 59 9143577

Web: www.my-iolite.com | **Email:** info@my-iolite.com